


ET / ETI




PLEASE NOTE: The access panel is available only on the painted steel ET Series models


Model	L	P	H	A	B	F Ø	G
ELCI	800	800	90	650	650	60	4 mm
ETA / ETAI	1.000	1.000	90	850	850	60	5 mm
ETM / ETMI	1.000	1.250	90	850	1.100	60	
ETB / ETBI	1.250	1.250	90	1.070	1.070	60	
ETD / ETDI	1.250	1.500	115	1.070	1.320	60	5 mm (optional 8 mm)
ETE / ETEI	1.500	1.500	115	1.320	1.320	60	
ETF / ETFI	1.500	2.000	130	1.300	1.800	60	6 mm
ETG-1 / ETGI-1	1.500	2.000	180	1.300	1.800	60	8 mm
ETH / ETHI	1.500	2.500	180	1.280	2.280	60	
ETL / ETLI	2.000	2.500	180	1.780	2.280	60	


dimensions in mm

ET / ETI

ETA / ETAI Drill Area




 Area wich you can drill


 Area wich can not be drilled


dimensions in mm

ET / ETI

ETB / ETBI Drill Area




 Area wich you can drill


 Area wich can not be drilled


dimensions in mm

ET / ETI

ETD / ETDI Drill Area




 Area wich you can drill


 Area wich can not be drilled


dimensions in mm

ET / ETI

ETE / ETEI Drill Area




 Area wich you can drill


 Area wich can not be drilled

dimensions in mm

ET / ETI

ETF / ETFI Drill Area




 Area wich you can drill

 Area wich can not be drilled

dimensions in mm

ET / ETI

ETG-1 / ETGI-1 Drill Area



Area wich you can drill






Area wich can not be drilled

dimensions in mm

ET / ETI


ETH / ETHI Drill Area





dimensions in mm

ET / ETI

ETL / ETLI Drill Area




 Area wich you can drill

 Area wich can not be drilled

dimensions in mm

ET / ETI

ETM / ETMI Drill Area



Area wich you can drill



Area wich can not be drilled

dimensions in mm